

---

# CHAPTER 2

---

## STORMWATER HYDROLOGY

### Table of Contents

#### SECTION 2.1 METHODS OF ESTIMATING STORMWATER RUNOFF

2.1.1 Introduction to Hydrologic Methods .....	2.1-1
2.1.2 Symbols and Definitions .....	2.1-3
2.1.3 Rainfall Estimation .....	2.1-5
2.1.4 Rational Method .....	2.1-8
2.1.4.1 Introduction .....	2.1-8
2.1.4.2 Application.....	2.1-8
2.1.4.3 Equations .....	2.1-8
2.1.4.4 Time of Concentration .....	2.1-9
2.1.4.5 Rainfall Intensity (I).....	2.1-10
2.1.4.6 Runoff Coefficient (C).....	2.1-10
2.1.4.7 Example Problem .....	2.1-11
2.1.5 SCS Hydrologic Method.....	2.1-16
2.1.5.1 Introduction .....	2.1-16
2.1.5.2 Application.....	2.1-16
2.1.5.3 Equations and Concepts.....	2.1-16
2.1.5.4 Runoff Factor .....	2.1-18
2.1.5.5 Urban Modifications of the SCS Method.....	2.1-20
2.1.5.6 Travel Time Estimation .....	2.1-23
2.1.5.7 Simplified SCS Peak Runoff Rate Estimation .....	2.1-27
2.1.5.8 Example Problem 1 .....	2.1-31
2.1.5.9 Hydrograph Generation .....	2.1.32
2.1.5.10 Example Problem 2 .....	2.1-36
2.1.6 U.S. Geological Survey Peak Flow and Hydrograph Method .....	2.1-38
2.1.6.1 Hydrograph Limitations .....	2.1-40
2.1.6.2 Rural (or Undeveloped) Basins.....	2.1-40
2.1.6.3 Rural (or Undeveloped) Basin Limitations .....	2.1-40
2.1.6.4 Example Problem .....	2.1-42

---

<b>2.1.7 Water Quality Volume Peak Flow .....</b>	<b>2.1-44</b>
<b>2.1.7.1 Water Quality Volume Calculation .....</b>	<b>2.1-44</b>
<b>2.1.7.2 Water Quality Volume Peak Flow Calculation .....</b>	<b>2.1-44</b>
<b>2.1.7.3 Example Problem .....</b>	<b>2.1-45</b>
<b>2.1.8 Water Balance Calculations</b>	
<b>2.1.8.1 Introduction .....</b>	<b>2.1-46</b>
<b>2.1.8.2 Basic Equations.....</b>	<b>2.1-46</b>
<b>2.1.8.3 Example Problem .....</b>	<b>2.1-49</b>
<b>2.1.9 Downstream Hydrologic Assessment.....</b>	<b>2.1-51</b>
<b>2.1.9.1 Reasons for Downstream Problems .....</b>	<b>2.1-51</b>
<b>2.1.9.2 The Ten-Percent Rule .....</b>	<b>2.1-52</b>
<b>2.1.9.3 Example Problem .....</b>	<b>2.1-53</b>

## **SECTION 2.2 STORAGE DESIGN**

<b>2.2.1 General Storage Concepts .....</b>	<b>2.2-1</b>
<b>2.2.1.1 Introduction .....</b>	<b>2.2-1</b>
<b>2.2.1.2 Storage Classification .....</b>	<b>2.2-2</b>
<b>2.2.1.3 Stage-Storage Relationship .....</b>	<b>2.2-2</b>
<b>2.2.1.4 Stage-Discharge Relationship .....</b>	<b>2.2-4</b>
<b>2.2.2 Symbols and Definitions .....</b>	<b>2.2-5</b>
<b>2.2.3 General Storage Design Procedures.....</b>	<b>2.2-5</b>
<b>2.2.3.1 Introduction .....</b>	<b>2.2-5</b>
<b>2.2.3.2 Data Needs.....</b>	<b>2.2-6</b>
<b>2.2.3.3 Design Procedure .....</b>	<b>2.2-6</b>
<b>2.2.4 Preliminary Detention Calculations .....</b>	<b>2.2-7</b>
<b>2.2.4.1 Introduction .....</b>	<b>2.2-7</b>
<b>2.2.4.2 Storage Volume.....</b>	<b>2.2-7</b>
<b>2.2.4.3 Peak Flow Reduction .....</b>	<b>2.2-8</b>
<b>2.2.5 Channel Protection Volume Estimation .....</b>	<b>2.2-8</b>
<b>2.2.5.1 Introduction .....</b>	<b>2.2-8</b>
<b>2.2.5.2 Basic Approach .....</b>	<b>2.2-8</b>
<b>2.2.5.3 Example Problem .....</b>	<b>2.2-9</b>
<b>2.2.6 The Modified Rational Method.....</b>	<b>2.2-12</b>
<b>2.2.6.1 Introduction .....</b>	<b>2.2-12</b>
<b>2.2.6.2 Design Equations .....</b>	<b>2.2-12</b>

---

## **SECTION 2.3 OUTLET STRUCTURES**

<b>2.3.1 Symbols and Definitions .....</b>	<b>2.3-1</b>
<b>2.3.2 Primary Outlets .....</b>	<b>2.3-2</b>
<b>2.3.2.1 Introduction .....</b>	<b>2.3-2</b>
<b>2.3.2.2 Outlet Structure Types.....</b>	<b>2.3-2</b>
<b>2.3.2.3 Orifices.....</b>	<b>2.3-3</b>
<b>2.3.2.4 Pipes and Culverts.....</b>	<b>2.3-6</b>
<b>2.3.2.5 Sharp-Crested Weirs .....</b>	<b>2.3-6</b>
<b>2.3.2.6 Broad-Crested Weirs .....</b>	<b>2.3-7</b>
<b>2.3.2.7 V-Notch Weirs.....</b>	<b>2.3-8</b>
<b>2.3.2.8 Proportional Weirs.....</b>	<b>2.3-9</b>
<b>2.3.2.9 Combination Outlets.....</b>	<b>2.3-9</b>
<b>2.3.3 Extended Detention (Water Quality and Channel Protection) Outlet Design.....</b>	<b>2.3-11</b>
<b>2.3.3.1 Introduction .....</b>	<b>2.3-11</b>
<b>2.3.3.2 Method 1: Maximum Hydraulic Head with Routing .....</b>	<b>2.3-11</b>
<b>2.3.3.3 Method 2: Average Hydraulic Head and Average Discharge.....</b>	<b>2.3-12</b>
<b>2.3.4 Multi-Stage Outlet Design.....</b>	<b>2.3-12</b>
<b>2.3.4.1 Introduction .....</b>	<b>2.3-12</b>
<b>2.3.4.2 Multi-Stage Outlet Design Procedure .....</b>	<b>2.3-13</b>
<b>2.3.5 Extended Detention Outlet Protection .....</b>	<b>2.3-15</b>
<b>2.3.6 Trash Racks and Safety Grates .....</b>	<b>2.3-17</b>
<b>2.3.6.1 Introduction .....</b>	<b>2.3-17</b>
<b>2.3.6.2 Trash Rack Design .....</b>	<b>2.3-18</b>
<b>2.3.7 Secondary Outlets .....</b>	<b>2.3-19</b>
<b>2.3.7.1 Introduction .....</b>	<b>2.3-19</b>
<b>2.3.7.2 Emergency Spillway Design.....</b>	<b>2.3-20</b>

## **References**

---

## LIST OF TABLES

2.1.1-1 Applications of the Recommended Hydrologic Methods .....	2.1-2
2.1.1-2 Constraints on Using Recommended Hydrologic Methods .....	2.1-2
2.1.2-1 Constraints on Using Recommended Hydrologic Methods .....	2.1-3
2.1.4-1 Frequency Factors for Rational Formula.....	2.1-9
2.1.4-2 Recommended Runoff Coefficient Values .....	2.1-15
2.1.5-1 Runoff Curve Numbers .....	2.1-21
2.1.5-2 Roughness Coefficients (Manning's n) for Sheet Flow.....	2.1-24
2.1.5-3 $I_a$ Values for Runoff Curve Numbers.....	2.1-28
2.1.5-4 Dimensionless Unit Hydrographs .....	2.1-34
2.1.6-1 USGS Rural Peak Equations .....	2.1-41
2.1.6-2 Flood Hydrograph.....	2.1-43
2.1.8-1 Water Balance Values for Atlanta, Georgia .....	2.1-47
2.1.8-2 Saturated Hydraulic Conductivity.....	2.1-48
2.1.8-3 Evaporation Monthly Distribution.....	2.1-48
2.1.8-4 Summary Information for Austin Aces .....	2.1-50
2.2.2-1 Symbols and Definitions.....	2.2-5
2.2.6-1 Rainfall Factors "a" and "b" for the Modified Rational Method .....	2.2-14
2.3.1-1 Symbols and Definitions.....	2.3-1
2.3.2-1 Circular Perforation Sizing .....	2.3-4
2.3.2-2 Broad-Crested Weir Coefficient (C) Values .....	2.3-8

## LIST OF FIGURES

2.1.3-1 Location of Rainfall Data Sites .....	2.1-6
2.1.3-2 Example IDF Curve (Athens, Georgia).....	2.1-6
2.1.3-3 Rainfall Isohyetal Lines (10-year, 24-hour values) .....	2.1-7
2.1.4-1 Rational Formula – Overland Time of Flow Nomograph .....	2.1-12
2.1.4-2 Manning's Equation Nomograph.....	2.1-13
2.1.4-3 Kinematic Wave Nomograph.....	2.1-14
2.1.5-1 Approximate Geographic Boundaries for SCS Rainfall Distributions .....	2.1-17
2.1.5-2 SCS Solution of the Runoff Equation .....	2.1-18
2.1.5-3 Composite CN with Connected Impervious Areas .....	2.1-22
2.1.5-4 Composite CN with Unconnected Impervious Areas .....	2.1-23
2.1.5-5 Average Velocities – Shallow Concentrated Flow.....	2.1-26
2.1.5-6 SCS Type II Unit Peak Discharge Graph.....	2.1-29
2.1.5-7 SCS Type III Unit Peak Discharge Graph.....	2.1-30
2.1.5-8 Dimensionless Unit Hydrographs for Peaking Factors of 484 and 300 ...	2.1-34
2.1.6-1 USGS Hydrologic Regions in Georgia .....	2.1-39

---

2.1.8-1	Average Annual Free Water Surface Evaporation (in inches) .....	2.1-49
2.1.8-2	Augusta Precipitation Information .....	2.1-50
2.1.9-1	Detention Timing Example.....	2.1-51
2.1.9-2	Effect of Increased Post-Development Runoff Volume with Detention on a Downstream Hydrograph.....	2.1-52
2.1.9-3	Example of Ten-Percent Rule .....	2.1-53
2.2.1-1	Examples of Typical Stormwater Storage Facilities.....	2.2-1
2.2.1-2	On-Line versus Off-Line Storage.....	2.2-2
2.2.1-3	Stage-Storage Curve.....	2.2-3
2.2.1-4	Double-End Area Method .....	2.2-3
2.2.1-5	Stage-Discharge Curve .....	2.2-4
2.2.4-1	Triangular-Shaped Hydrographs .....	2.2-7
2.2.5-1	Detention Time vs. Discharge Ratios .....	2.2-9
2.2.5-2	Approximate Detention Basin Routing for Rainfall Types I, IA, II, and III .....	2.2-10
2.2.6-1	Modified Rational Definitions.....	2.2-12
2.3.2-1	Typical Primary Outlets.....	2.3-2
2.3.2-2	Orifice Definitions .....	2.3-5
2.3.2-3	Schematic of Orifice Plate Outlet Structure .....	2.3-5
2.3.2-5	Sharp-Crested Weir.....	2.3-6
2.3.2-6	Broad-Crested Weir .....	2.3-7
2.3.2-7	V-Notch Weir .....	2.3-8
2.3.2-8	Proportional Weir Dimensions.....	2.3-9
2.3.2-9	Schematic of Combination Outlet Structure .....	2.3-10
2.3.2-10	Composite Stage-Discharge Curve .....	2.3-10
2.3.4-1	Riser Flow Diagrams.....	2.3-14
2.3.4-2	Weir and Orifice Flow .....	2.3-14
2.3.5-1	Reverse Slope Pipe Outlet.....	2.3-15
2.3.5-2	Hooded Outlet .....	2.3-15
2.3.5-3	Half-Round CMP Orifice Hood .....	2.3-16
2.3.5-4	Internal Control for Orifice Protection .....	2.3-16
2.3.6-1	Example of Various Trash Racks Used on a Riser Outlet Structure .....	2.3-17
2.3.6-2	Minimum Rack Size vs. Outlet Diameter.....	2.3-19
2.3.7-1	Emergency Spillway .....	2.3-20

---

**This page left intentionally blank.**